Instruction Sheet

July, 2013

## High Density Pilot Device Housing

For use in 12" and 18" Plug-In units with 3RT10 contactors
Holds a maximum of four 22mm pilot devices

Quantity	Description
1	Pilot Device Housing
4	20mm Flush Hole Plugs
1	10-32 x 3/8" Screw

Installation

1. Insert hinges (1) into slots in right hand
    front side angle of plug-in unit.

2. Attach keyhole slot tab (2) to the screw
    in unit top plate.

3. Install four flush hole plugs into round holes (3)
    of Pilot Device Housing.

Front View

Side View

For replacement parts information or an
application guide, visit our website at
www.usa.siemens.com/mcc or contact
your local Siemens sales office.