



	⚠ DANGER
	HAZARDOUS VOLTAGE WILL CAUSE DEATH OR SERIOUS INJURY. DISCONNECT POWER BEFORE WORKING ON EQUIPMENT.

INSTALLATION INSTRUCTIONS:

MAIN BREAKER ASSEMBLY CATALOG NO.					
MEK060 (E09671)	MEK070 (E09672)	MEK080 (E09673)	MEK090 (E09674)	MEK100 (E09675)	MEK125 (E09677)
FOR USE ONLY WHERE SPECIFIED ON PANEL LABEL					

REMOVE FILLER PLATES OR TWISTOUTS FROM MAIN BREAKER OPENING IN TRIM.