Item: Class "R" Fuse Adapter Kit


(Kit Catalog Numbers shown below)

## For use with:

Fused Enclosed Switches, Panelboards, and Bus Plugs

Pc. No. 410415A01

## Installation Instructions for these Class "R" Fuse Adapter Kits






## SAFETY INSTRUCTIONS

Note: This instruction outlines recommended installation procedure.

- 1. Turn OFF the power supplying the device.
- 2. Turn the device OFF.
- 3. Add the Class "R" fuse adapters to each pole on the load base only.
  - A. Insert shell and drive rivet into the fuse clip assembly (Fig. 1).



**FUSE CLIP ASSEMBLY** 

Fig. 1

| System               | Kit                                |
|----------------------|------------------------------------|
| 100 Amp, 240 or 600V | HX363RF, SSRK33,<br>W55365, W63864 |
| 200 Amp, 240 or 600V | HX364RF, SSRK34,<br>W55366, W63865 |
| 400 Amp, 240 or 600V | HX365RF, SSRK35,<br>W55367         |
| 600 Amp, 240 or 600V | HX366RF, SSRK36,<br>W55368         |

- B. Squeeze drive rivet pin and shell together until the drive rivet pin is flush with the head (Fig. 2).
- 4. Remove backing from the fusing label and attach in a visible area near the load base.
- 5. Install Class "R" fuses.
- 6. Replace all shields and close cover before turning power ON.




Fig. 2

Siemens Industry Inc. Norcross,GA 30092 U.S.A. Assembled in Mexico