




# Pushbutton Units and Indicator Lights

## Class 50 Standard Duty Pushbutton Stations

5A 600V AC NEMA B600

### Selection and ordering data

	Actuator identification	Degree of protection	Contacts / voltage	Number of command points	Order No.	Weight approx.	Packs
						lbs.	Unit
1 unit surface mount-momentary pushbutton 	A = Momentary flush pushbutton green, surface, label "START"	NEMA 1	1NO - 1NC with common jumper (50ZAC1)	1	50AA3D		1
	A = Momentary flush pushbutton red, surface, label "STOP"	NEMA 1		1	50AA3E		1
	A = Momentary raised pushbutton red, surface, label "STOP"	NEMA 1		1	50AA3F		1
	A = Momentary mushroom head red, surface, label "STOP"	NEMA 1		1	50AA3G		1
	A = Momentary flush pushbutton less insert, surface	NEMA 1		1	50AA3A		1
	A = 3 position selector switch, surface, label "HAND-OFF-AUTO"	NEMA 1	2 NO 2SPST (50ZAC8)	1	50AA3C3		1
1 unit flush mount-momentary pushbutton 	A = 3 position selector switch, surface, label "Off-On"	NEMA 1		1	50AA3C6		1
	A = 2/3 selector switch, surface, multiple legends	NEMA 1		1	50AA3B9		1
	A = Indicator light, red, surface	NEMA 1	120/240V dual voltage 120PSB lamp	1	50BA3Y		1
	A = Indicator light, green, surface	NEMA 1		1	50BA3Z		1
	A = Indicator light, less lens, surface	NEMA 1		1	50BA32		1
	A = Momentary flush pushbutton green, flush, label "START"	NEMA 1B	1NO - 1NC with common jumper (50ZAC1)	1	50AA2D		1
	A = Momentary flush pushbutton red, flush, label "STOP"	NEMA 1B		1	50AA2E		1
	A = Momentary raised pushbutton red, flush, label "STOP"	NEMA 1B		1	50AA2F		1
	A = Momentary flush pushbutton less insert, flush	NEMA 1B		1	50AA2A		1
	A = Momentary flush pushbutton less insert, flush, chrome plate	NEMA 1B		1	50AA6A		1
	A = 3 position selector switch, flush, label "HAND-OFF-AUTO"	NEMA 1B	2 NO 2SPST (50ZAC8)	1	50AA2C3		1
	A = 3 position selector switch, flush, label "Off-On"	NEMA 1B		1	50AA2C6		1
	A = 2/3 selector switch, multiple legends, flush	NEMA 1B		1	50AA2B9		1
	A = 2/3 selector switch, multiple legends, chrome plate, flush	NEMA 1B		1	50AA6B9		1
A = Indicator light, red, flush	NEMA 1B	120/240V dual voltage	1	50AA2Y		1	
A = Indicator light, green, flush	NEMA 1B		1	50AA2Z		1	
A = Indicator light, less lens, flush	NEMA 1B		1	50AA22		1	
A = Indicator light, less lens, chrome plate, flush	NEMA 1B	120PSB lamp	1	50AA62		1	
2 unit surface mount-momentary pushbutton 	B = Momentary pushbutton green, surface, label "START"	NEMA 1	1NO, 1NC (50ZAC2)	2	50CA3DE		1
	A = Momentary pushbutton red, surface, label "STOP"						
	B = Momentary pushbutton green, surface, label "START"	NEMA 1	1NO, 1NC (50ZAC2)	2	50CA3DF		1
	A = Momentary raised pushbutton red, surface, label "STOP"						
	B = Momentary pushbutton green, surface, label "START"	NEMA 1	1NO, 1NC (50ZAC2)	2	50CA3DG		1
	A = Momentary mushroom head pushbutton red, surface, label "STOP"						
	B = Momentary pushbutton, less insert, surface	NEMA 1	1NO, 1NC (50ZAC2)	2	50CA3AA		1
	A = Momentary pushbutton, less insert, surface						
B = Momentary pushbutton, surface, label "FORWARD"	NEMA 1	2 NO (50ZAC3)	2	50DA3KL		1	
A = Momentary pushbutton, surface, label "REVERSE"							

# Pushbutton Units and Indicator Lights

## Class 50 Standard Duty Pushbutton Stations

5A 600V AC NEMA B600

### Selection and ordering data

Actuator identification	Degree of protection	Contacts / voltage	Number of command points	Order No.	Weight approx.	
					lbs.	Unit
B = Momentary pushbutton, surface, label "OPEN" A = Momentary pushbutton, surface, label "CLOSE"	NEMA 1	2 NO (50ZAC3)	2	50DA3HJ		1
B = Momentary pushbutton, surface, label "UP" A = Momentary pushbutton, surface, label "DOWN"	NEMA 1	2 NO (50ZAC3)	2	50DA3NP		1
B = Momentary pushbutton, surface, less insert A = Momentary pushbutton, surface, less insert	NEMA 1	2 NO (50ZAC3)	2	50DA3AA		1
B = Momentary pushbutton, surface, label "FORWARD" A = Momentary pushbutton, surface, label "REVERSE"	NEMA 1	2 NO mechanically inter-locked (50ZA3C w/ 50ZAM)	2	50RA3KL		1
B = Momentary pushbutton, surface, label "OPEN" A = Momentary pushbutton, surface, label "CLOSE"	NEMA 1	2 NO mechanically inter-locked (50ZA3C w/ 50ZAM)	2	50RA3HJ		1
B = Momentary pushbutton, surface, label "UP" A = Momentary pushbutton, surface, label "DOWN"	NEMA 1	2 NO mechanically inter-locked (50ZA3C w/ 50ZAM)	2	50RA3NP		1
B = Momentary pushbutton, surface, label "ON" A = Momentary pushbutton, surface, label "OFF"	NEMA 1	2 NO mechanically inter-locked (50ZA3C w/ 50ZAM)	2	50RA334		1
B = Momentary pushbutton, less insert surface A = Momentary pushbutton, less insert, surface	NEMA 1	2 NO mechanically inter-locked (50ZA3C w/ 50ZAM)	2	50RA3AA		1
B = Momentary pushbutton, surface, label "FORWARD" A = Momentary pushbutton, surface, label "REVERSE"	NEMA 1	2 NO, 2 NC (2 - 50ZAC2)	2	50EA3KL		1
B = Momentary pushbutton, surface, label "OPEN" A = Momentary pushbutton, surface, label "CLOSE"	NEMA 1	2 NO, 2 NC (2 - 50ZAC2)	2	50EA3HJ		1
B = Momentary pushbutton, surface, label "UP" A = Momentary pushbutton, surface, label "DOWN"	NEMA 1	2 NO, 2 NC (2 - 50ZAC2)	2	50EA3NP		1
B = Momentary pushbutton, surface, label "ON" A = Momentary pushbutton, surface, label "OFF"	NEMA 1	2 NO, 2 NC (2 - 50ZAC2)	2	50EA334		1
B = Momentary pushbutton, surface, less insert A = Momentary pushbutton, surface, less insert	NEMA 1	2 NO, 2 NC (2 - 50ZAC2)	2	50EA3AA		1
B = Momentary pushbutton green, flush, label "START" A = Momentary pushbutton red, flush, label "STOP"	NEMA 1B	1NO, 1NC (50ZAC2)	2	50CA2DE		1
B = Momentary pushbutton green, flush, label "START" A = Momentary raised pushbutton red, flush, label "STOP"	NEMA 1B	1NO, 1NC (50ZAC2)	2	50CA2DF		1
B = Momentary pushbutton green, flush, label "START" A = Momentary mushroom head pushbutton red, flush, label "STOP"	NEMA 1B	1NO, 1NC (50ZAC2)	2	50CA2AA		1
B = Momentary pushbutton, less insert, flush A = Momentary pushbutton, less insert, flush	NEMA 1B	1NO, 1NC (50ZAC2)	2	50CA6AA		1

2 unit flush mount-momentary push-button



# Pushbutton Units and Indicator Lights

## Class 50 Standard Duty Pushbutton Stations

5A 600V AC NEMA B600

### Selection and ordering data

Actuator identification	Degree of protection	Contacts / voltage	Number of command points	Order No.	Weight approx.	Packs
					lbs.	Unit
B = Momentary pushbutton, flush, label "FORWARD" A = Momentary pushbutton, flush, label "REVERSE"	NEMA 1B	2 NO (50ZAC3)	2	50DA2KL		1
B = Momentary pushbutton, flush, label "OPEN" A = Momentary pushbutton, flush, label "CLOSE"	NEMA 1B	2 NO (50ZAC3)	2	50DA2HJ		1
B = Momentary pushbutton, flush, label "UP" A = Momentary pushbutton, flush, label "DOWN"	NEMA 1B	2 NO (50ZAC3)	2	50DA2NP		1
B = Momentary pushbutton, less insert, flush A = Momentary pushbutton, less insert, flush	NEMA 1B	2 NO (50ZAC3)	2	50DA2AA		1
B = Momentary pushbutton, less insert, chrome plate, flush A = Momentary pushbutton, less insert, chrome plate, flush	NEMA 1B	2 NO (50ZAC3)	2	50DA6AA		1
B = Momentary pushbutton, flush, label "FORWARD" A = Momentary pushbutton, flush, label "REVERSE"	NEMA 1B	2 NO mechanically interlocked (50ZA3C w/ 50ZAM)	2	50RA2KL		1
B = Momentary pushbutton, flush, label "OPEN" A = Momentary pushbutton, flush, label "CLOSE"	NEMA 1B	2 NO mechanically interlocked (50ZA3C w/ 50ZAM)	2	50RA2HJ		1
B = Momentary pushbutton, flush, label "UP" A = Momentary pushbutton, flush, label "DOWN"	NEMA 1B	2 NO mechanically interlocked (50ZA3C w/ 50ZAM)	2	50RA2NP		1
B = Momentary pushbutton, flush, label "ON" A = Momentary pushbutton, flush, label "OFF"	NEMA 1B	2 NO mechanically interlocked (50ZA3C w/ 50ZAM)	2	50RA234		1
B = Momentary pushbutton, less insert, flush A = Momentary pushbutton, less insert, flush	NEMA 1B	2 NO mechanically interlocked (50ZA3C w/ 50ZAM)	2	50RA2AA		1
B = Momentary pushbutton, less insert, chrome plate, flush A = Momentary pushbutton, less insert, chrome plate, flush	NEMA 1B	2 NO mechanically interlocked (50ZA3C w/ 50ZAM)	2	50RA6AA		1
B = Momentary pushbutton, flush, label "FORWARD" A = Momentary pushbutton, flush, label "REVERSE"	NEMA 1B	2 NO, 2 NC (2 - 50ZAC2)	2	50EA2KL		1
B = Momentary pushbutton, flush, label "OPEN" A = Momentary pushbutton, flush, label "CLOSE"	NEMA 1B	2 NO, 2 NC (2 - 50ZAC2)	2	50EA2HJ		1
B = Momentary pushbutton, flush, label "UP" A = Momentary pushbutton, flush, label "DOWN"	NEMA 1B	2 NO, 2 NC (2 - 50ZAC2)	2	50EA2NP		1
B = Momentary pushbutton, flush, label "ON" A = Momentary pushbutton, flush, label "OFF"	NEMA 1B	2 NO, 2 NC (2 - 50ZAC2)	2	50EA234		1
B = Momentary pushbutton, less insert, flush A = Momentary pushbutton, less insert, flush	NEMA 1B	2 NO, 2 NC (2 - 50ZAC2)	2	50EA2AA		1
B = Momentary pushbutton, less insert, chrome plate, flush A = Momentary pushbutton, less insert, chrome plate, flush	NEMA 1B	2 NO, 2 NC (2 - 50ZAC2)	2	50EA6AA		1

3 unit surface mount



# Pushbutton Units and Indicator Lights

## Class 50 Standard Duty Pushbutton Stations

5A 600V AC NEMA B600

### Selection and ordering data

Actuator identification	Degree of protection	Contacts / voltage	Number of command points	Order No.	Weight approx.	
					lbs.	Unit
B = Momentary pushbutton green, surface, label "START" A = Maintained selector switch, surface, label "HAND-OFF-AUTO"	NEMA 1	1NO, 1NC (50ZAC1) 2 NO 2SPDT w/ common jumper (50ZAC8)	2	50FA3DC3		1
B = Momentary pushbutton less insert, surface A = Maintained selector switch, multiple legends, surface	NEMA 1	1NO, 1NC (50ZAC1) 2 NO 2SPDT w/ common jumper (50ZAC8)	2	50FA3AB9		1
B = Indicator light, red, surface A = Maintained selector switch, surface, label "HAND-OFF-AUTO"	NEMA 1	120/240V dual voltage (120PSB lamp) 2 NO 2SPDT w/ common jumper (50ZAC8)	2	50HA3YC3		1
B = Indicator light, red, surface A = Maintained selector switch, multiple legends, surface	NEMA 1	120/240V dual voltage (120PSB lamp) 2 NO 2SPDT w/ common jumper (50ZAC8)	2	50HA32B9		1
B = Indicator light, green, surface A = Indicator light, red, surface	NEMA 1	120/240V dual voltage (120PSB lamp)	2	50GA3ZY		1
B = Indicator light, less lens, surface A = Indicator light, less lens, surface	NEMA 1	120/240V dual voltage (120PSB lamp)	2	50GA322		1
B = Momentary pushbutton green, flush, label "START" A = Maintained selector switch, flush, label "HAND-OFF-AUTO"	NEMA 1B	1NO, 1NC (50ZAC1) 2 NO 2SPDT w/ common jumper (50ZAC8)	2	50FA2DC3		1
B = Momentary pushbutton less insert, flush A = Maintained selector switch, multiple legends, flush	NEMA 1B	1NO, 1NC (50ZAC1) 2 NO 2SPDT w/ common jumper (50ZAC8)	2	50FA2AB9		1
B = Momentary pushbutton less insert chrome plate, flush A = Maintained selector switch, multiple legends, flush	NEMA 1B	1NO, 1NC (50ZAC1) 2 NO 2SPDT w/ common jumper (50ZAC8)	2	50FA6AB9		1
B = Indicator light, red, flush A = Maintained selector switch, flush, label "HAND-OFF-AUTO"	NEMA 1B	120/240V dual voltage (120PSB lamp) 2 NO 2SPDT w/ common jumper (50ZAC8)	2	50HA2YC3		1
B = Indicator light, less lens, flush A = Maintained selector switch, multiple legends, flush	NEMA 1B	120/240V dual voltage (120PSB lamp) 2 NO 2SPDT w/ common jumper (50ZAC8)	2	50HA22B9		1
B = Indicator light, less lens, chrome plate, flush A = Maintained selector switch, multiple legends, flush	NEMA 1B	120/240V dual voltage (120PSB lamp) 2 NO 2SPDT w/ common jumper (50ZAC8)	2	50HA62B9		1
B = Indicator light, green, flush A = Indicator light, red, flush	NEMA 1B	120/240V dual voltage (120PSB lamp)	2	50GA2ZY		1
B = Indicator light, less lens, flush A = Indicator light, less lens, flush	NEMA 1B	120/240V dual voltage (120PSB lamp)	2	50GA222		1
B = Indicator light, less lens, chrome plate, flush A = Indicator light, less lens, chrome plate, flush	NEMA 1B	120/240V dual voltage (120PSB lamp)	2	50GA622		1
C = Momentary pushbutton, surface, label "FORWARD" B = Momentary pushbutton, surface, label "REVERSE" A = Momentary pushbutton, surface, label "STOP"	NEMA 1	2 NO, 2 NC (2 - 50ZAC2) 1NO - 1NC with common jumper (50ZAC1)	3	50MA3KLE		1
C = Momentary pushbutton, surface, label "UP" B = Momentary pushbutton, surface, label "DOWN" A = Momentary pushbutton, surface, label "STOP"	NEMA 1	2 NO, 2 NC (2 - 50ZAC2) 1NO - 1NC with common jumper (50ZAC1)	3	50MA3NPE		1
C = Momentary pushbutton, surface, label "OPEN" B = Momentary pushbutton, surface, label "CLOSE" A = Momentary pushbutton, surface, label "STOP"	NEMA 1	2 NO, 2 NC (2 - 50ZAC2) 1NO - 1NC with common jumper (50ZAC1)	3	50MA3HJE		1

3 unit surface mount



# Pushbutton Units and Indicator Lights

## Class 50 Standard Duty Pushbutton Stations

5A 600V AC NEMA B600

### Selection and ordering data

Actuator identification	Degree of protection	Contacts / voltage	Number of command points	Order No.	Weight approx.		Pack
					lbs.	Unit	
C = Momentary pushbutton, surface, label "FAST" B = Momentary pushbutton, surface, label "SLOW" A = Momentary pushbutton, surface, label "STOP"	NEMA 1	2 NO, 2 NC (2 - 50ZAC2) 1NO - 1NC with common jumper (50ZAC1)	3	50MA3TUE			1
C = Momentary pushbutton, surface, label "START" B = Momentary pushbutton, surface, label "JOG" A = Momentary pushbutton, surface, label "STOP"	NEMA 1	2 NO, 2 NC (2 - 50ZAC2) 1NO - 1NC with common jumper (50ZAC1)	3	50MA3DME			1
C = Momentary pushbutton, surface, label less insert B = Momentary pushbutton, surface, label less insert A = Momentary pushbutton, surface, label less insert	NEMA 1	2 NO, 2 NC (2 - 50ZAC2) 1NO - 1NC with common jumper (50ZAC1)	3	50MA3AAA			1
C = Momentary pushbutton, surface, label "START" B = Momentary pushbutton, surface, label "STOP" A = Maintained selector switch, surface, label "HAND-OFF-AUTO"	NEMA 1	1 NO, 1 NC (50ZAC2) 2 NO, 2 SPST with common jumper (50ZAC8)	3	50LA3DEC3			1
C = Momentary pushbutton, less insert, surface B = Momentary pushbutton, less insert, surface A = Maintained selector switch, multiple legends, surface	NEMA 1	1 NO, 1 NC (50ZAC2) 2 NO, 2 SPST with common jumper (50ZAC8)	3	50LA3AAB9			1
C = Indicator light, red, surface B = Momentary pushbutton, surface, label "START" A = Momentary pushbutton, surface, label "STOP"	NEMA 1	120/240V dual voltage (120PSB lamp) 1 NO, 1 NC (50ZAC2)	3	50JA3YDE			1
C = Indicator light, green, surface B = Momentary pushbutton, surface, label "START" A = Momentary pushbutton, surface, label "STOP"	NEMA 1	120/240V dual voltage (120PSB lamp) 1 NO, 1 NC (50ZAC2)	3	50JA3ZDE			1
C = Indicator light, less lens, surface B = Momentary pushbutton, less insert, surface A = Momentary pushbutton, less insert, surface	NEMA 1	120/240V dual voltage (120PSB lamp) 1 NO, 1 NC (50ZAC2)	3	50JA32AA			1
C = Indicator light, green, surface B = Indicator light, red, surface A = Maintained selector switch, surface, label "HAND-OFF-AUTO"	NEMA 1	120/240V dual voltage (120PSB lamp) 2 NO, 2 SPST with common jumper (50ZAC8)	3	50NA3ZYC3			1
C = Indicator light, less lens, surface B = Indicator light, less lens, surface A = Maintained selector switch, multiple legends, surface	NEMA 1	120/240V dual voltage (120PSB lamp) 2 NO, 2 SPST with common jumper (50ZAC8)	3	50NA322B9			1